

Installation Instructions

Position tree stake firmly in the ground, leaning at a 75 degree angle against the direction of the prevailing wind. For best results, the tree stake should intersect the tree trunk between 3 and 4 feet above the ground or about halfway up the trunk, if the tree is smaller than 6 feet.

Cut sufficient length of ProLock® Chain Lock Tree Tie to easily wrap around both, the tree stake and the tree itself. It's a good idea to cut a little extra length, so that it can be adjusted as the tree grows.

Wrap the cut strip of ProLock® around both, the tree stake and the tree, feeding the chain through itself, then twisting and locking it snugly. Adjust regularly to avoid damage to the tree bark.

