

Installation Instructions

(Using Landscape Stakes and Pre-drilled Slots)

Using a straight edge spade, make a trench along the bed area where edging is to be installed. Trench should be approx. 4" deep, depending on desired finished edging height.



Slide connectors into track system with locking pegs facing toward pre-drilled holes on each edging piece. Locking pegs should click into pre-drilled holes on each of the edging pieces, providing a clean, locked joint without overlapping.

Place edging in the trench with the track groove toward the planting bed. Installers may find it easier to connect all pieces before placing edging in trench.



Pound stakes, flange pointed downward, through the pre-drilled slots at a 45-degree angle. Use extra stakes at curves, spaced evenly throughout.

Tightly pack soil around edging and install landscape fabric and ground cover (decorative stone, mulch, etc.) to the top of the edging.

