

Installation Instructions (Using Spikes and Spike Anchoring Adaptors)

Using a straight edge spade, make a trench along the bed area where edging is to be installed. Trench should be approx. 4" deep, depending on desired finished edging height.



Slide spike-anchoring adaptors into track system prior to connecting pieces. Recommended spacing between spikes is 32" (max.). Use extra adaptors at or near curves or for additional support when holding back heavier types of decorative stone.

Slide connectors into track system with locking pegs facing toward pre-drilled holes on each edging piece. Locking pegs should click into pre-drilled holes on each of the edging pieces, providing a clean, locked joint without overlapping.



Place edging in the trench with the track groove toward the planting bed. Installers may find it easier to connect all pieces before placing edging in trench.

Drive spikes vertically, through loops on spike adaptor until spike head is against the adaptor. Recommended spacing between spikes is 32" (maximum). Use extra adaptors at or near curves or for additional support when holding back heavier types of decorative stone.



Tightly pack soil around edging and install landscape fabric and ground cover (decorative stone, mulch, etc.) to the top of the edging.